# Installing the SigPlus® software

*** Do not connect the signature pad until install completes successfully ***

1. Place the SigPlus® Electronic Signature ActiveX Software CD into your computer's CD-ROM drive. If the setup program does not start automatically, you can run the installmenu.exe file found on the CD.
2. Choose "Install SigPlus eSignatures (must be installed first)"
3. On the Welcome screen, click **Next**.
4. After reading the Read Me File, click **Next**.
5. Choose a Destination Location or use the default. Click **Next** to continue.
6. Select the version of Windows you are using. Click **OK** to continue.
7. Select "SignatureGem LCD 1X5 (T-L462)" from the list of tablets. Click **OK** to continue.
8. Select "HSB" from the list of connection types. Click **OK** to continue.
9. Make sure the signature pad is not connected and click **OK** to continue.
10. Review the License Agreement and click **Agree** to continue.
11. Select "No" to not create a shortcut for Demo Ocx.exe. Click **OK** to continue.
12. Click **OK** on the SigPlus Documentation Directory message.
13. Click **OK** on the SigPlus Plug-Ins, Tools, and Examples message.
14. Click **OK** on the HSB Support message.
15. Click **Finish** to complete installation.
16. Click **Cancel** on the Topaz Systems SigPlus eSignature Installation screen, followed by clicking **Exit Setup** on the pop-up message box.

# Installing the images used on the signature pad

1. **RUN** the "sigPadImages.EXE" file found in the Forms $\Rightarrow$ NESIIS User Manuals
2. Click **OK** on the "Choose Your Language" message box. English is the default.
3. Click **NEXT** on the Welcome to SigPadImages Setup Wizard message box.
4. On the Choose Install Location message box, *do not change* the default destination folder and select **INSTALL.**
5. Click **NEXT** on the Installation Complete message box.
6. Click **FINISH** on the Completing the sigPad Images Setup Wizard message box.